



1. Place the base on a flat surface.
2. Insert one end of a wire divider into an open slot on the base. Squeeze the other end of the divider into the open slot on the opposite side of the base. Release to lock in place.
3. Repeat with remaining dividers, positioning as necessary to properly fit your items. We recommend fitting the dividers as close as possible to keep everything upright and easy to remove.