


Mini Moderno™ Ultrasonic Essential Oil Diffuser INSTRUCTIONS

PARTS



FEATURES

Ultrasonic vibrations transform your essential oil and water into healthy, fragrant mist.

1. Water Capacity: 70 mL (2.37 fl oz)
2. Coverage Area: Up to 100 sq ft
3. Continuous Operation: Up to 4 hrs
4. Intermittent Operation: Up to 8 hrs at 30-sec intervals
5. Light Mode: Rotating, freeze color, and Off
6. Automatic safety shut-off
7. Power: Includes USB Cable (fits into any standard USB Port)

CARE & MAINTENANCE

Only use the power cord supplied with the unit. Always remove the power cord before cleaning. Essential oil should not come in contact with the exterior surface of the unit.

TO CLEAN:

* SpaRoom® KLENZOR™ tablets may be used to renew diffuser to like-new condition.


Remove Top Cover. Empty the water away from Air Outlet. The ceramic disc, located in the bottom of the Water Tank, should not come in contact with any hard or sharp objects. To remove possible buildup, gently use a cotton swab dipped in white vinegar to wipe out the inside.

Dry with a soft cloth to avoid mineral buildup. Do not use strong cleaning agents.

INSTRUCTIONS FOR USE

Place diffuser on a flat, water-resistant surface.

1. Remove the Top Cover from the Base.
2. Plug the Connector of the USB Cable into the DC Socket in the back of the unit.
3. Fill the Water Tank with tap water up to the Max Water Level Line. Do not overfill or mist output may be low. Add 3 to 5 drops of essential oil to the Water Tank.
4. Replace the Top Cover onto the Base.
5. Plug the USB End of the USB Cable into any USB Port.
6. **Button Functions:**
 - 1st Push = Continuous mist with rotating colors
 - 2nd Push = Intermittent mist with rotating colors
 - 3rd Push = Intermittent mist with freeze color
 - 4th Push = Turns unit off



NOTES:

- The unit will automatically turn off when water level becomes too low.
- Disconnect USB Cable from power source when not in use.