

# soy candles makers kit

{ PDF Printable How-To Guide }

---

**materials:** candle containers  
1 lb. soy candle wax  
wicks  
fragrance oil (optional)  
fragrance testing strips  
wax color block (optional)  
wax paper & warning labels

---

## steps:

1. Decide which fragrance oil to use, a blend of both, or none at all.  
Place a drop onto a testing strip to smell all fragrance notes.
2. Melt wax slowly.  
Option A. Crock Pot on lowest setting.  
Option B. Double Boiler.  
Place a metal or glass heat-safe bowl over a pot of hot water.  
Stir until wax is fully melted, it will be semi-transparent.  
**Note:** Microwaving is not recommended as hot wax is flammable.
3. Add wax color chip, optional. 1/2 a block will lightly color the wax and a full block will give your candle a deeper tint. Opt out of this option if you want to make natural, additive free candles.
4. Slowly stir-in fragrance oils, optional.
5. Place candle containers on wax paper (for easier clean up), and dip the ends of each wick into the melted wax. Quickly stick the tabs onto the bottom of each container while the wax is still warm.
6. Slowly & carefully pour wax into each container, starting with the largest.
7. Cool at room temperature for at least 2 hours or until solid and apply warning labels to the bottom of each candle. Trim wicks to 1/4".